



COMARK

A Fluke Company

Comark DT400

Pocket digital thermometer



Comark's DT400 digital thermometer has a thin tip and comes with a one-year warranty.

The DT400 pocket digital thermometer has a large digit display visible from the top of the instrument. By using the maximum hold button, you can switch between the maximum reading and the current temperature reading.

The DT400 pocket digital thermometer can be used for food temperature checks and the thin tip probe gives a response within 6 seconds.

It is a waterproof thermometer and durable enough to use for checking the final rinse cycle temperature of commercial dishwashers.

Comark uses BioCote®, the only antimicrobial solution to be awarded HACCP International Certification, to provide an important extra level of defence against cross-contamination.

Features

- Extended Range -20°C to 200°C , -4°F to 400°F
- High Accuracy $\pm 0.5^{\circ}\text{C}/1^{\circ}\text{F}$
- Field Calibratable
- Commercial dishwasher safe
- Maximum temperature hold verifies the rinse temperature in commercial dishwashers
- Auto power off conserves battery life
- One Year Warranty

The Professionals' Choice

Comark DT400

Pocket Digital Thermometer



Comark Instruments

52 Hurricane Way
Norwich, Norfolk, NR6 6JB
United Kingdom
Tel: +44 (0) 207 942 0712
Fax: +44 (0) 207 942 0714
Email: sales@comarkinstruments.com

Comark Instruments

P.O. Box 500
Beaverton, OR 97077, USA
Tel: +1 (503) 643 5204
Toll Free: (800) 555 6658
Fax: +1 (503) 627 5311
Email: sales@comarkusa.com



Specifications

| | |
|-------------------------------|---|
| Temperature Measurement Range | -20°C to +200°C / -4°F to +400°F |
| Accuracy | ±0.5°C / 1°F |
| Stem Length | 127mm / 5" |
| Probe Tip Diameter | 1.5mm |
| Response Time | Under 6 seconds |
| Sample Time | 1.5 seconds |
| Environmental Protection | BioCote Antimicrobial Protection |
| Certification | NSF Listed |
| Battery Type | 1.5 V Button Cell battery (Part no. AB13; LR44) |
| Waterproof | Yes |
| Warranty | 1 Year Limited |

For more details please see www.comarkinstruments.com

BioCote®

Selected Comark thermometers, probes and data loggers have BioCote's silver technology incorporated into instrument cases and probe handles at the time of manufacture. The antimicrobial finish inhibits the growth of bacteria, reducing the risk of cross-contamination and infection in the environment. BioCote® has been officially recognised for its benefits within the food industry with HACCP International Certification. HACCP International Certification supports organisations that demonstrate food safety excellence in non-food products that are designed for, or are commonly used in, the food industry. BioCote® is the only antimicrobial solution to be awarded HACCP International Certification.

Warranty

All Comark instruments have a minimum one year warranty unless otherwise stated. The warranty for temperature probes is six months and all other probes are unwarranted because the conditions of use are beyond our control. The Comark Warranty covers manufacturing defects and component failure and applies worldwide. In line with our policy of continuous development, we reserve the right to alter any product specification without notice. Comark has an accredited UKAS (NIST equivalent) calibration laboratory for temperature and humidity measurement and offers full service and recalibration facilities.

Comark Instruments is committed to providing quality and affordable products to the food service industry. Our thermometers and humidity testers bring speed, accuracy and reliability to the transport, testing and storing of food under HACCP guidelines. A large variety of products, well-trained staff, and a commitment to customer satisfaction mean you can come to us for answers to all your temperature measurement needs!

All rights reserved. Data subject to alteration without notice. All trademarks are the property of their respective owners. Modification of this document is not permitted without written permission from Comark Instruments.

© 2017 Comark Instruments Part No. 20526-1

The Professionals' Choice